



BNR 40564

A place for the bathrobe and a chic detail for the bathroom. Very contemporary in matt black and minimalist in design. A harmonious addition to all the current home trends: Industrial style, Scandinavian style or neutral. The powder-coated holder is easily and effortlessly attached to the wall without drilling using the tesa® adhesive solution. Additionally, it's also suitable to hold larger shower towels. Without any manual skills, without the usual mess and without drilling holes. Therefore also ideal for rented flats.

Features

- Easy and clean installation without drilling thanks to the convenient all-in-one adhesive solution with tesa® Power.Kit technology
- Industrial style design trend: The perfect accessory for bathrooms with an industrial style design
- The ideal accessory for colour concepts in black and white - can be combined in one colour or as a contrast
- An eye-catcher for modern bathroom ambiences and for neutral design concepts
- Can be appreciated in many different ways: Industrial style, vintage look, retro look, modern and also great for bathrooms with loft character.
- Our tip: An attractive must have for bathrooms in Scandinavian style
- For unconventional combinations: Straightforward in design as well as a great accent for classic or romantic style inspired bathrooms
- tesa® MOON BLACK bathroom hook, matt black powder-coated metal
- Harmoniously rounded, organic design, round wall plate
- Adheres to glazed tiles, metal, natural stone, marble, concrete, glass, wood and many plastics
- The adhesive included in the scope of delivery must cure for 12 hours
- Easy to install, leaves no drill holes, can be removed again without damaging the surface - therefore also a good solution for rented flats.
- Reusable after removal with a new mounting adapter BK20 - the matching adapter is also available separately.
- Not suitable for plaster, wallpaper, wall textiles and plastics such as PP, PE and PTFE.
- Dimensions: 50mm x 65mm x 53mm

Technical Data

Application

Mounting

1. Clean the surface
2. Peel off the protective film of the adapter
3. Attach the adapter to the wall
4. Fill in the glue with the glue applicator
5. Allow to cure for 12 hours
6. Mount the accessory on the adapter with the help of an Allen key

Disassembly

1. Disassemble the accessory from the adapter
2. Turn off the adapter with a pipe wrench
3. If necessary, remove adhesive residues with a glass scraper

Disclaimer

tesa® products prove their impressive quality day in, day out in demanding conditions and are regularly subjected to strict controls. All information and recommendations are provided to the best of our knowledge on the basis of our practical experience. Nevertheless tesa SE can make no warranties, express or implied, including, but not limited to any implied warranty of merchantability or fitness for a particular purpose. Therefore, the user is responsible for determining whether the tesa® product is fit for a particular purpose and suitable for the user's method of application. If you are in any doubt, our technical support staff will be glad to support you.

