



Battery Replacement Instructions



① Insert the flat blade of a small screw-driver into the pry-off slot of remote controller, pry up to open the back cover.

② Replace with 1x CR2032 battery.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- ① This device may not cause harmful interference.
- ② This device must accept any interference received, including interference that may cause undesired operation.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Made in China

DRCH1 V1.3

The User Manual of Remote Controller



Features

The remote controller is an accessory of series smart alarm system. It helps you quickly arm/disarm/home arm/trigger SOS the system.


It's small and exquisite, convenient for carrying out on keychain or in pocket/bag.

Customized shortcut button, provide convenience to self define your personal command.

Parameters

• Working Voltage	DC 3V
• Battery	1 × CR2032 button battery (3V)
• Working Current	≤35mA
• Standby Current	≤10μA
• Transmission Distance	Up to 180m without obstacle
• Transmission Frequency	433.92MHz / 868.35MHz
• Working Temperature	-10°C~50°C
• Humidity	≤90%rh (non-condensing)
• Weight	15.7g(battery not included) 22g(battery included)
• Dimension	74.4x34.5x16.1mm LxWxH(±0.1mm)

Appearance



LED Indication

LED flashes once: Button is pressed and transmitter sends signal to the main panel.

The LED indicator will light up once in 15 seconds in case of low battery. Please replace the battery in time.

Push notification will be sent to your APP.

Pairing with Main Panel


- ① Scanning the QR Code for Pairing.
- ② The pairing result can be confirmed on App.

Hint: How to trigger


Press and hold any button of the remote controller for about 0.5s.

Operating Clarification


• Arm

Press , the LED indicator lights on, the system enters armed status.


• Disarm

Press , the LED indicator lights on, the system enters disarmed status.


• Home Arm

Press , the LED indicator lights on, the system enters home armed status.

• SOS

Press , the LED indicator lights on, the system immediately enters emergency alarming status.

• Shortcut Button

 Customized this shortcut button in the App, the system will execute the command you self-defined immediately.